
Visit our website and find more help documents at shuttercase.com, or drop us an email at help@shuttercase.com if any questions.

We are always here to help.

Designed in USA by Shuttercase Inc Distributed Worldwide by VANTASTEK CO.,LIMITED www.shuttercase.com

Copyright@2018 Shuttercase Inc. All Rights Reserved.

Shuttercase User Manual





Welcome!

We are so excited to have you with us. Shuttercase is made by photo-hobbyists who are engineers, for photo-hobbyists who shoot by smartphones. It takes us 36 months of research and design, 8 versions of making and remaking prototypes, countless days and nights of discussions and brain-storms, to finally bring a faint sparkle in mind to a solid tool now in your hand. We believe we will make mobile photography easier and better, with you.

Take out your phone, mount our case, and unleash your creative power now.

Sincerely, Shuttercase Team







- * USB cable (for charging the battery grip)
- * Operating Manual (this manual)


Getting started

OINSERT LENS MOUNT PLATE Slide the lens mount plate from the top of the case. Push down untill you feel the click.


If in your packing the lens mount is already put on, please pass this step and go to the next page directly.









PUT IN YOUR PHONE. Insert one side of your phone horizontally in the case as the illustration. Then push the other side of the phone into the case.



To take out your phone, pull the bottom corner upwards as the illustration, and then pull out the whole phone.







Press and push along the groove

Step 2




Now, you are set. Time to shoot!

To remove the camera handle, push it to the opposite direction as contray to step 2.

How to shoot by Shuttercase

To achieve best ergonomics, we recommend holding the case as below illustration. Put thumb on the thumb button, in order to to ease your hand fatigue during long time constant shooting. Put forefinger on the shutter button to press and shoot.



Please note: You need to activate your phone's shooting mode before pressing shutter button to shoot. The shutter button inside the case is pure mechanical, no bluetooth needed, so that you are not bound by a single App and is faster to shoot, no worry about unsable bluetooth connection or power consumption.

Optimized Shooting Procedure:

Just turn on your smartphone's imbedded camera App and start shooting. Wont' take you more than 3 seconds. Capture the decisive moments and post-edit by pro third party App like VSCO or Snapseed.


How to mount and remove add-on lens

Shuttercase is an open platform and will be compatible with a list of add-on lenses in coming time. Currently, we are compatible with Moment Lens (Moment Inc.) V2 (second version). For first time users, we recommend mounting lens before inserting phone.

Please Note: If you are Moment lens user with iPhone Xs/X or Xs Max, you can only mount the Moment lens on iPhone's first lens (28mm-equivalent). Shuttercase for iPhone Xs/X/Xs Max doen't support Moment lens on the second iPhone lens. Shuttercase for iPHone 8Plus/7Plus can support Moment lenses working on both the first and second iPhone lenses.


m

① Align the white dash on the lens to the sign () on the top of the case. Press lens in. This is to fit the metal hook at the bottom of lens into the lens plate concave.



How the lens and case look from inside when you align properly. This illustration shows the mechanism of how lens matches the case. This angle is not visible if phone is already put in the case.

@Rotate lens clockwise 90° until you see the dash on lens aligning vertical to the edge of the case.




How the lens and case look from inside when you align properly. This illustration shows the mechanism of how lens matches the case. This angle is not visible if phone is already put in the case.

3 To dis-attach the lens, rotate it counter-clockwise 90° to the position of step 1. Gently pulls lens out.


How to use powerbank function

Shuttercase is embeded with a 3000mAh powerbank in the camera handle.


10 HOW TO CHARGE PHONE



Slowly PRESS AND PUSH handle along the groove. You'll see a cable embedded in the bottom.




Pull out the charging cable and stretch it out.



VERY IMPORTANT:

Pls keep the cable raising slightly higher than case body below so that it won't get scratched.



Step 4

When the camera handle is all pushed in, plug cable into your phone. A blue LED will turn on and the charging begins. When fully charged, it can charge iPhone X and Xs from around 10% to 70%, iPhone 7Plus and 8 Plus from 5% to 77%. The data may vary under different testing environment or using conditions. When battery completely exhausted, LED goes off.

(Step 5)

To stop charging: pull out cable and slide off the handle. Reverse step 4 to 1: plug cable back to the bottom and slide the handle back on the case. (IMPORTANT:) NOTE ①

TO raise the cable higher than case body below so that it won't get scratched or tangled when sliding.

How to charge the battery


Battery Specs

Capacity: 3000mAH/11.1Wh

Input/Output: 5V 1A

A Grade battery
Smart IC protection

We have put a micro-USB/USB-A cable included in the packing. Plug the micro
USB end to the battery grip's micro-USB input port,



and the cable's big USB head to any standard USB-A port.

A red LED will flash to signal the charging.

When fully charged, the red LED stays on stable.


It takes around 6 hours to charge the battery from empty to full.

Note: You can also use a USB-C/micro-USB cable. As long as your cable has a micro-USB interface to connect to the grip's micro-USB input port, the other end of your cable can be USB-C or USB-A.


Daily use as a protective case

Remove the camera handle and slide on the hand grip, then you will get a thin protective case, easy and light for everyday use.

How to slide on the hand grip



Note to push to the direction as the arrow points when sliding in the hand grip. Wrong direction might cause damage to the case groove.



Press and push the handgrip along the groove. You will hear/feel a clear click when it reaches the end and completely sits in position.